

4.7. Teste Modbus TCP para RTU

Por padrão, os dados da porta serial e da porta de rede é transmitido de forma transparente. Se necessitar converter o protocolo Modbus TCP para RTU, é necessário selecionar a opção **Modbus_TCP Protocol** no campo **Transfer Protocol** no menu **Device Settings**.

Após a seleção a porta da interface altera automaticamente para 502, o software Modbus TCP do usuário é conectado à porta 502 do IP da interface, os comandos Modbus TCP que foram enviados serão convertidos em comandos RTU e enviados dispositivo Modbus.

Por exemplo, se o servidor serial receber o comando Modbus TCP **00 00 00 00 00 06 01 03 00 00 0a**, a porta serial envia o comando **01 03 00 00 00 0a c5 cd**.

The screenshot shows the 'Device Settings' window with the following configurations:

- Device Info:** Virtual Serial: COM2, Dev Type: (empty), Dev Name: EICETH485, Dev ID: 285FC17A2439, Firmware Ver: V1.452.
- Function of the device:** ☐ Web Download, ☒ DNS System, ☒ REAL_COM Protocol, ☒ Modbus TCP To RTU, ☒ Serial Commnad, ☒ DHCP Support, ☐ Storage Extend, ☒ Multi-TCP Connection.
- Network:** IP Mode: Static, IP Address: 192 . 168 . 1 . 254, Port: 502 (highlighted with a red box), Work Mode: TCP Server, Net Mask: 255 . 255 . 255 . 0, Gateway: 192 . 168 . 1 . 1, Dest. IP/Domain: 192.168.1.2, Dest. Port: 4196.
- Serial:** Baud Rate: 57600, Data Bits: 8, Parity: None, Stop Bits: 1, Flow Control: None.
- Advanced Settings:** DNS Server IP: 192 . 168 . 0 . 1, Dest. Mode: Dynamic, Transfer Protocol: Modbus_TCP Protocol (highlighted with a red box), Keep Alive Time: 60 (s), Reconnet Time: 12 (s), Http Port: 80, UDP Group IP: 230 . 90 . 76 . 1, ☐ Register Pkt: (empty), ☐ ASCII, ☐ Restart for no data every 300 Sec., ☐ Enable send parameter every 5 Min., More Advanced Settings... button.
- Framing Rule:** Max Frame Length: 1300 (Byte), Max Interval(Smaller will better): 3 (Ms).

Buttons at the bottom: Get Default, Save As Default, Load Default, Modify Key, Firmware/Config, Restart Dev, Modify Setting, Cancel.

Se o software Modbus TCP do usuário necessitar a utilização como escravo, é necessário alterar o modo de trabalho para **TCP Client** com base no protocolo de conversão e altere o IP de destino para o IP do computador onde o software Modbus TCP está localizado e a porta de destino é 502, conforme mostrado na figura abaixo.

Device Settings

×

Device Info

Virtual Serial
COM2

Dev Type

Dev Name
EICETH485

Dev ID
285FC17A2439

Firmware Ver
V1.452

Function of the device

☐ Web Download
☒ DNS System
☒ REAL_COM Protocol
☒ Modbus TCP To RTU
☒ Serial Commnad
☒ DHCP Support
☐ Storage Extend
☒ Multi-TCP Connection

Network

IP Mode
Static

IP Address
192 . 168 . 1 . 254

Port
0

Work Mode
TCP Client

Net Mask
255 . 255 . 255 . 0

Gateway
192 . 168 . 1 . 1

Dest. IP/Domain
192.168.1.2
Local IP

Dest. Port
502

Serial

Baud Rate
57600

Data Bits
8

Parity
None

Stop Bits
1

Flow Control
None

Advanced Settings

DNS Server IP
192 . 168 . 0 . 1

Dest. Mode
Dynamic

Transfer Protocol
Modbus_TCP Protocol

Keep Alive Time
60
(s)

Reconnet Time
12
(s)

Http Port
80

UDP Group IP
230 . 90 . 76 . 1

☐ Register Pkt:
☐ ASCII

☐ Restart for no data
every
300
Sec.

☐ Enable send parameter
every
5
Min.

More Advaced Settings...

Framing Rule

Max Frame Length
1300
(Byte)

Max Interval(Smaller will better)
3
(Ms)

Get Default
Save As Default
Load Default

Modify Key
Firmware/Config

Restart Dev
Modify Setting
Cancel

Revision #1

Created 31 May 2026 13:58:14 by Electools

Updated 31 May 2026 13:58:14 by Electools